

Live Update for Touch Screen SourceMeter Models: 2450, 2460, 2461 and 2470

This mode allows you to scroll to change a source value or source limit while the output is on.

To set values using live update mode with the scroll wheel:

1. With the output on, press the control to select the setting.
2. Press and hold the **ENTER** key until *Live Update* is displayed.
3. Press the scroll wheel to enable editing.
4. Turn the scroll wheel to select digit to edit.
5. Press the scroll wheel to enable editing.
6. Turn the scroll wheel to desired value. Value will update live.



To turn off live update mode:

1. Press the control to select the setting.
2. Press and hold the **ENTER** key until *Live Update* disappears.
3. The normal operation is active.